



To use CMOS version of Si570:
Remove R8 and U5 from circuit
and jumper between hole of
R8 and hole connected
to U5 pin 5.

SoftRock Projects

SoftRock Lite+USB Xtall v9.0

Tony KB9YIG	Rev 1 9/24/08	Page 1 of 3
-------------	------------------	-------------